BROTHER TONER CARTRIDGE REPLACEMENT INSTRUCTION

1. Hold down the lock lever on the left side of the drum unit and pull the old toner cartridge out.
2. Remove the new toner from the packaging, removing the protective plastic covering to expose the drum roller.
3. Insert the new toner cartridge in the drum unit until it clicks into place. If you put it in properly, the lock lever will lift automatically back into place.
4. Clean the primary corona wire inside the drum unit by gently sliding the tab at the bottom of the drum unit from right to left several times. Return the blue tab to the Home position.
5. Install the drum unit and toner cartridge assembly into the machine.

BROTHER DRUM UNIT REPLACEMENT INSTRUCTION

For HL Series Follow these steps to replace the drum unit:

1. Open the front cover.
2. Take out the drum unit and toner cartridge assembly.
3. Remove the toner cartridge from drum unit but pushing down on the lock lever on the left side.
4. Put the toner cartridge firmly into the NEW drum unit. It should click into place with the lock lever coming back up into place.
5. Put the drum unit and toner cartridge back into the machine, keep the front cover open.
6. Press and hold Go button for about 4 seconds until the LEDS light up. Once all four LEDS are lit, release the Go button.
7. Close the front cover.
8. Make sure the drum LED is off before using.

For MFC Series Follow these steps to replace the drum unit:

1. Open the front cover.
2. Install the drum unit and toner cartridge assembly in the MFC (detailed instructions for installing new drum unit in the HL series instructions)
3. Press Options on the printer.
4. To confirm you are installing a new drum, press 1, then 5. When the LCD shows Accepted, close the front cover.

For DCP Series Follow these steps to replace the drum unit:

1. Press the cover release button and open the front cover.
2. Remove the old drum unit and toner cartridge assembly.
3. Wait to unpack the new drum unit until immediately before installing it. Place the old drum unit into the plastic bag and discard it according to local regulations.
4. Reinstall the toner cartridge into the new drum unit.
5. Reinstall the new drum unit, keeping the front cover open.
6. Press Clear/Back.
7. Press 1 and when the LCD shows Accepted, close the front cover.

Note: Do not reset the drum counter when you only replace the toner cartridge.